



## INSTALLATION INSTRUCTIONS

### MAILBOX DECALS

#### STEP 1

Gather supplies - mailbox numbers, (not included: tape, and ruler).  
Note: vinyl should not be applied in wet or freezing conditions.



#### STEP 2

Clean and dry the mailbox surface.  
Measure the desired number location.  
Place a piece of tape to align the bottom of the numbers.



#### STEP 3

Peel off the number backing and align with tape guide. Press numbers firmly onto mailbox. Apply even pressure along the entire surface.



#### STEP 4

Slowly remove the front transfer film and tape.