MODERN | HOUSF | NUMBERS

www.modernhousenumbers.com



INSTALLATION INSTRUCTIONS

NUMBERS AND LETTERS

STEP 1

Gather supplies: house numbers, template, studs, spacers, (not included: tape, epoxy, hammer, rubber mallet, drill, level). Note: masonry, concrete, and stone may require hammer drill.

STEP 2

Tape template at desired location. Use a level to align template. Drill holes according to template. Use 11/64" drill bit (specialty 3/16" bit for masonry or rock).

STEP 3

Apply epoxy to one end of the stud.











STEP 4

Push studs into pre-drilled holes on the back of the number. Light tapping with a hammer may be required. If so, place on a soft surface. Take care not to scratch the face of the number.

STEP 5

Slide spacers over studs and apply epoxy to the end of the exposed studs.

STEP 6

Push number into holes. Light tapping with a rubber mallet may be required.

CARING FOR YOUR PRODUCTS:

To extend the effective life of your numbers and plaques, clean them every six months or every three months in coastal or industrial regions. Use a soft cloth and a mild household detergent solution to remove dust, salt, and other deposits.

Rinse gently with clean, fresh water. Dry with non-abrasive towel.

Love your Modern House Numbers? Send your best photos to photos@modernhousenumbers.com.