



INSTALLATION INSTRUCTIONS

SINGLE USE CURB STENCIL DECAL

STEP 1

Gather supplies - curb stencil, (not included: spray paint, paper roll, and masking tape). Note: curb stencil should not be applied in wet or freezing conditions.



STEP 2

Clean concrete surface of loose debris and press stencil firmly and evenly onto concrete at desired location. Remove front transfer film. Tape all edges.



STEP 3

Protect adjacent surfaces with paper. Paint stencil. Be careful not to over spray.



STEP 4

Allow paint to dry. Once dry, slowly remove stencil.